

Equine Leave-On Conditioner *w/Microsil® Finish*

<u>FORMULATION:</u>	<u>% WT.</u>
1. Deionized Water	88.85
2. Microsil® Finish CHEMSILSILICONES INC. <i>Water (and) Amodimethicone (and) Cetrimonium Bromide (and) Cetrimonium Chloride (and) Propoxytetramethyl Piperdinyl Dimethicone (and) Trideceth-6 (and) C11-15 Pareth-7</i>	10.00
3. Lincoside H Lincoln Fine Ingredients <i>DMDM Hydantoin</i>	0.40
4. Polysorbate-20	0.60
5. Fragrance	0.15

PROCEDURE:

1. Combine ingredients 1-3 in order and mix for 15 minutes.
2. Combine fragrance and polysorbate-20 and blend until uniform.
3. Add fragrance mix to batch and combine mix for 10 minutes.

CRL-11-30C

01.2012

STATEMENTS AND METHODS PRESENTED ARE BASED UPON THE BEST AVAILABLE INFORMATION AND PRACTICES KNOWN TO CHEMSIL SILICONES, INC. AT PRESENT, BUT ARE NOT REPRESENTATIONS OR WARRANTIES OF PERFORMANCE, RESULT OR COMPREHENSIVENESS, NOR DO THEY IMPLY ANY RECOMMENDATIONS TO INFRINGE ANY PATENT OR AN OFFER OF LICENSE UNDER ANY PATENT.

We Provide **YOUR** Silicone Solutions™